

NOTICE OF ASSEMBLE

Tips for assembling

- 1. Picures shown on the package may be slightly different from the actual product.
- 2. All the materials are taken in the operation step, put the remaining materials back into the original pocket until the installation is completed. (Avoid material loss during installation)
- 3. The dimensions indicated in the step diagram are "cm".
- 4. If there have template paper material, please cut the material according to the template to avoid mistakes...
- 5. According to the part rule example at the bottom of this page, refer to the part on the part number drawing, find the material object and compare with the material list, confirm and install. (Wooden parts only)
- 6. Glue should not be applied too much, so as not to dry longer, overflow will affect the effect of the finished product.
- 7..Part shapes may differ from the photographs depending on he production batch

Tips for Assembling Wood




Use a knife to smooth out the burr


Or use sandpaper to smooth

Testing on LED function

Be sure to test the LED lights before making the lighting, note that the LED white wire to the negative, gray wire to the positive reference to the following figure operation test.



How to assemble the battery holder



- Battery holder, LED bulb, tape, screw driver and 2 piece AAA size battery (not provided)

use a knife in the connection point

gently press, you can take out the wood.

2. Use screw driver and take the lid off from the battery holder.

3. Insert the battery take notes on the polarity.

out the burr

4. Connect the red wire to grey wire. Connect the black wire to white

5. Wrap the exposed wire with the tapes.

6. Place the box lid and fastness with screw driver.

Examples of parts rule:

A01: The parts are directly in the box: B01: The parts are in the B bag; C01: The parts are in the C bag, and so on (Note: The printing paper is displayed in the step A28-01: The printing paper is placed directly in the box, The part number is A28-01) Note: Materials A23, A24, A25 and A26 are placed in the material bag A.

Contents

Name	Makariala Da akara
Name	Materials Package
Printing paper	A Bag A28、A29、A30(all printing paper and template paper are set in the A28、A29、A31 paper accessories, a total of 9 pieces of A3 single-sided printing Paper + 1 piece cardboard paper)
cupboard	A bag + B bag + M bag + J bag + printing paper page 3
kitchen accessories	Jbag+Kbag+Lbag+Mbag+Nbag+printging paper page 4-5
sundry rack	A bag+B bag+J bag+K bag+L bag+N bag+printging paper page 5-7
dining table	Bbag+Jbag+Kbag+Lbag+Mbag+Nbag+printingpaper page 7-9
tea table	A bag+B bag+J bag+K bag+L bag+M bag+N bag+printging paper page 9-10
japanese koto	$A bag + C bag + K bag + L bag + M bag + pringing paper \\ \hspace*{1.5cm} page 10$
bed	A bag + C bag + L bag + M bag page 10-12
bathroom accessories	A bag + C bag + J bag + K bag+ printing paper page 12
cabinet	A bag + C bag + K bag + M bag + P bag + printing paper page 12-13
bookcase	A bag + C bag + printing paper page 13-14
writing desk	A bag + D bag + K bag + L bag + M bag + printing paper page 14-15
lights	A bag+D bag+L bag+M bag+P bag+printing paper page 15-16
umbrella	Jbag+Kbag+Lbag+Pbag+printingpaper page 16-17
potted plant	Jbag+Kbag+Lbag+Mbag+Nbag+printingpaper page 17-18
door and window	A bag + D bag + M bag + printing paper page 18
woodenshoe	A bag + D bag + printing paper page 18-19
wall&stairs&raft	A bag + E bag + L bag + P bag + printing paper page 19
outer frame assembly	A bag + printing paper page 20-21
first floor assembly	A bag+D bag+E bag+printing paper page 21-22
bathroom wall panel	A bag + J bag + L bag + printing paper page 23
door and window on the second floor	Ebag+Mbag+printing paper page 23
second floor assembly	A bag + E bag + F bag + K bag + L bag + P bag + printing paper page 23-25
roof tile	A bag
window,doors and lighting on the third floor	A bag + F bag + K bag + M bag + P bag + printing paper page 26-27
third floor assembly	A bag + E bag + G bag + K bag + N bag + P bag + printing paper page 27-29
hot spring	A bag+Gbag+Jbag+Kbag+Pbag page 29-30
rockery	Hbag+Kbag+Pbagpage 30-31
ground lamp	A bag+ H bag+ K bag+ L bag + M bag + N bag + P bag + printing paper page 31
plants	A bag + L bag + N bag + printing paper page 31
garden assessories	A bag + H bag + L bag + printing paper page 32
garden assembly	Hbag+Lbag+Mbag+Nbag+Pbag+printingpaper page 32-35
Installation of battery box	P bag + printing paper page 35-36



Welcome to the DIY world, now follow me to start.

Thumbnail of material list (reference only)













Thumbnail of printing paper & template paper (reference only)






















Symbol description used















attention to the direction of installation material B sticerial A







parts on both












fold double edge to center dotted line

Fold four sides

es Pay attention to th le material B















































































































































































cut all the LED light wires to the same length peel off the film of the LED light wires and then wrap it together in the same color.

9



Put all gray wires with battery box red wires together , and put all white wires with battery box black wire together Wrap the bare wires with adhesive tape P04. Make sure the LED lights are on.

8



Statement: the lamp wires cannot be inserted into the output socket.

- Can use 2*AAA batteries

- Please notice the place of anode and cathode when pit in the batteries

- Rechargeable batteries are not blunt electricity

- Rechargeable batteries can only be charged under adult supervision

- Rechargeable batteries should be removed from the toy before charging

- Different types of batteries cannot mix;


Do not mix new batteries in use with semi-used batteries

- Do not mix new batteries in use with semi-used batteries.

 Run out of battery should be removed from the toy

 The power shall not be short circuit

Put the battery holder in it (be careful not to touch the wind-up of the music machine).









Installation of dust cover

