

# NOTICE OF ASSEMBLE

#### Bring your own tools



Scissors: Can be used to cut printed paper, cloth, etc.

Screw Driver: For fixing screws, mostly canbe used to install doors and music components.

Tweezers: For holding small materials and rolling up iron wire.

Cutter kinfe: For peeling off power wire skin and cutting

For measuring materials to identify the number of materials so as to enhance off materials. work efficiency.

## **!**\Warnings

- The product is not suitable for children under 14 years old. The should be under custody of adults when playing with the product.
- There are small parts, please do not swallow them for avoiding dangerous accidents.

#### Making tips

- 1. LED wiring indication: White=Positive; Grey=Negative.
- 2.Use a craft blade to carefully skim over the plastic to bare the copper wire.
- please refer to the below steps:




3. For LED wiring extension,



Twist the copper of both LED wire and extension wire together.



Do the same on the white wire.
Remarks: Tie a knot at the end of the grey wire to differentiate the polarity.



Place the duly twist wire on the tapes provided.





Roll and wrap the wire. Place another wire next to it. Remarks: DO NOT contact both copper wire to avoid short circuit.



Roll and wrap it together.

#### Tips for assembling

- 1. Picures shown on the package may be slightly different from the actual product. 2. Please use the provided tracing paper for cutting purpose to achieve the best
- 3. Product designs and specification may be subject to change without advance notice for purpose of making improvement. 4. Testing on LED function:



DO NOT contact the LED wire end direct to the battery cell.



Use the provide battery holder. Make sue the correct polarity.

#### How to assemble the remote control lamp



1.Material needed:
- Remote controller, receiver, LED buld, tape and 3pieces button battery.(provided)



2. Connect the red wire to grey wire. Connect the black wire to white wire.



3. Wrap the exposed wire with the tapes.



4. Insert the battery take notes on the polarity.




5. Bend the sheet iron on receiver as shown.




The remote controller aimed at receiver, press the ON button key to light.

# Product information



#### Kitchen Cabinet



#### Roaster



#### Cabinet



#### Round table



#### Sofa



## Dressing Table



# Bed B121 C09 (A16-50) C22 (A16-51) Part 1 Cut out C09 and C22 according to the template of A16-50 and A16-51, attach them together as shown C16 (A16-52) Cut out C16 according to the template of A16-52, cover up part 1 with C16 as shown. C09 (A16-53) Paste B118 to combination as shown. Cut out C09 according to the template of A16-53, attach it on the bed as shown. C18:7cm C19: 22cm C02 (A16-55) Cut out C02 according to the template of A16-55, apply the glue according to the red lines as shown. Fold the cloth in half insert some cotton to C21 as shown. Apply the glue on the top and fix it as shown, the pillow is done (2 pieces) C17 (A16-56 Repeat above same steps to make other pillows. C07 (A16-59) Attach C20(4cm) on the pillow as shown. C06 (A16-57)


# Rocking-chair



#### Bathroom



#### Bathroom




# Swing C10 (A16-80) LED Light line:4cm/ Attach C10 on A16-80 and cut out, fold it as shown. Use the tool to make two small hole on the side of C10 as shown. B146 B145 (2 pieces) Follow the steps as shown in diagram to make the swing Cut off A16-81, fold it well, cut the dotted line as shown. Fold A16-81 as shown. Use a tool to make a small hold on the middle of windmill. Follow the steps as shown in diagram to make the windmill


#### Piano




## Swimming pool




#### Grass room



# Chandelier



#### Outer Frame



#### Outer Frame



#### Outer Frame



#### How to connect to battery box

Statement: the lamp wires cannot be inserted into the output socket.

—Please notice the place of anode and cathode when pit in the batteries

- Rechargeable batteries are not blunt electricity

-- Rechargeable batteries can only be charged under adult supervision

-- Rechargeable batteries should be removed from the toy before charging — The power shall not be short circuit

-- Run out of battery should be removed from the toy


Different types of batteries cannot mix;

Do not mix new batteries in use with semi-used batteries.





1.Trim all the LED wiring to the same length.
2.Use a craft blade to carefully skim over the plastic to bare the copper wire. Twist the same colour wire together.



Insert the battery take notes on the polarity.



 Twist the following wire together:
 (I) BLACK wire from the battery box with the WHITE wire from LED bulb. (I) BLACK wire from the battery box with the WHITE wire from LED bulb.

4. Roll and seal the duly twist copper with the white tape provided.

(II) RED wire from the battery box with the GREY wire from LED bulb.



**Installation of dust proof cover** (For updated version, the parts need to be purchased separately)




F04 Transparent cover 0.18\*1.5\*32 (1piece)



F05 Transparent cover 0.18\*24\*32 (2pieces)



F06 Transparent cover 0.18\*21.14\*24 (2pieces)



2. Paste F04, F05, and F06 together to complete the dust proof cover as shown.

#### Photo of Dust proof cover



# Photo Gallery

















